V9939C to V-9937





FIGURE 3
LOCATION AND NUMBERING OF CONNECTION BLOCK



# Wiring Arrangement 1

### Page Access:

- a. Connect V-9937 pin 2 to page port Tip.
- b. Connect pin 17 to page port Ring.

#### Override Access:

- a. Connect V-9937 pin 1 to override trunk (or override line key) Tip.
- \_\_\_ b. Connect pin 16 to override Ring.

#### Control Leads:

- a. Connect V-9937 pin 3 to one side of page port dry contact closure.
- b. Connect pin 18 to the other side of the dry contact closure.

## **Music Input:**

- a. Connect pin 4 of the V-9937 to one side of the music source output.
- b. Connect pin 19 to the other side of the music output.

NOTE: Use a low level music source such as a tuner. DO NOT connect the output of a high power amplifier to the Valcom unit.



